

### Service check list

R=replace or change L=lubricate I=inspect A=adjust N=not optional

12 months/20.000 kilometers

		kms	kms	kms	Kms	
Service intervals at every 5.000 kilometers		5000	10000	15000	20000	Comments
<b>Engine compartment</b>						
1	Engine oil and sump plug washer	R	R	R	R	
2	Engine oil filter	R	R	R	R	
3	Engine coolant/condition	I	I	I	I	
4	Fuel filter	R	R	R	R	
5	Air cleaner element	R	R	R	R	
6	Brake and clutch fluid	I	I	I	R	
7	Spark plugs/glow plugs	I	I	I	I	
8	Vacuum pump oil hose	I	I	I	I	
9	V-belts	I	I	I	I	
10	Radiator hose	I	I	I	I	
11	Engine timing belts/timing chain	I	I	I	I	
12	Intake air hose and turbo charger oil hose	I	I	I	I	
13	Engine and gearbox - check mounting	I	I	I	I	
14	Battery and terminals	I	I	I	I	
15	Valve clearance	I	I	I	I	
16	Electrical connector and wires	I	I	I	I	
17	Power steering oil	I	I	I	I	
<b>Below the vehicle</b>						
18	Transmission and transfer oil	I	I	I	R	
19	Automatic transmission oil	I	I	I	R	
20	Differential gear oil	I	I	I	R	
21	Steering free play - check and adjust	I	I	I	I	
22	Lubricate suspension arms, steering leakage, propeller shaft	I	L	I	L	
23	Tie rod end	I	L	I	L	
24	Suspension system - check for damages or looseness	I	I	I	I	
25	Arm ball joints for play and dust cover damage	I	I	I	I	
26	Schock absorbers fron and rear - check	I	I	I	I	
27	Exhaust pipe and mounting	I	I	I	I	
28	Axle front and rear	I	I	I	I	
29	Bolts and nuts on chassis and body	I	I	I	I	
<b>Interior</b>						
30	Brake paddle and parking brake	I	I	I	I	
31	Seat slides, seat belts and cabin lights	I	I	I	I	
<b>Exterior</b>						
32	Front and rear brake	I	I	I	I	
33	Brake disc / drum thickness / diameter	I	I	I	I	
34	Front and rear wheel bearings - check for play / lubricate	I	I	I	I	
35	Fuel hoses and pipes - check for leakage	I	I	I	I	
36	Light, horn, mirrors wiper, washer - check and adjust	I	I	I	I	
<b>Other</b>						
37	Body condition	I	I	I	I	
38	Air conditioning/heather system - check function	I	I	I	I	
39	Tire rotation	A	A	A	A	
40	Wheel alignment	I	I	I	I	
41	Reflectors front and rear - c heck		I		A	
42	Door bonnet and hinges - check and lubricate	I	I	I	I	
43	Door and window rubbers - check and grease with silicone	I	I	I	I	
44	Tire pressure front and rear - check and adjust	A	A	A	A	
45	Tire thread / tire condition	I	I	I	I	
46	OBD read out		I		I	